



395mm Undermount

425mm Inset

Before cutting the worktop material please read these important notes

**Inset Installation: Professional installation recommended**

Bowl or Drainer

- 1/Check Worktop is level.
- 2/Using the Inset Template ensure position is correct on the worktop before marking around with a pencil.
- 3/Drill a hole on the inside of the template line large enough to take a jig-saw blade. Cut around the inside of this line carefully.
- 4/Seal the cut edge using varnish,gloss paint or silicone.
- 5/Fit Clamps and Waste fittings.
- 6/Fit Sink in position and hand tighten clamps. Apply a small bead of silicone around the edge of the sink to prevent water seepage.

**Under-mount Installation: Professional installation recommended**

Bowl or Drainer

- 1/ The Under-mount Template cut-out provided here is to the exact size of the bowl.  
**As the Installer** you must choose whether to remain with this cut-out dimension which will leave the edge of the worktop flush with the edge of the bowl or ADD a set back or SUBTRACT an overhang.
- 2/ Check Worktop is level.
- 3/ Using the Under-mount Template ensure position is correct on the worktop before marking around with a pencil. Drill and cut the worktop.
- 4/ Turn Worktop upside down and apply a bead of Silicone Sealant between the surfaces to seal and position under-mount sink.
- 5/ Position the Under-mount fittings evenly around the rim and fix.
- 6/ Ensure any cut surfaces are sealed against water seepage with paint or Silicone sealant.

FUN 993.0207.179

